


### TEMPERATURE CHART



#### BOOSTER T°

MIN MAX

**START:** 0°C +40°C

**CHARGE:** 3°C +40°C

**STORAGE:** 0°C +30°C







#### AMBIENT T°

MIN MAX


**START:** -20°C +40°C

**CHARGE:** 3°C +40°C

**STORAGE:** 0°C +30°C




3



✓ OK!

4




3




**FAULT**

4



**.....WAIT 5 MIN**

5




**! MAX 5 ENGINE START**




1

**AFTER START**




2



**.....WAIT 2H**

3

**CHARGE**  
3°+40°



Charging



**DON'T USE!**

